

ENGLISCH
FÜR DEUTSCH BITTE WENDEN

QUICK GUIDE

PIEGA CONNECT
Premium Wireless by PIEGA

EXPECT MORE



PIEGA CONNECT
Premium Wireless by PIEGA

QUICK GUIDE

Thank you!

We are pleased that you have chosen our Premium Wireless by PIEGA. With the help of this quick guide, we would like to introduce you to your musical experience in a simple and quick way.

How can you use it?

To activate your newly acquired PIEGA Connect, simply follow the steps below.

More detailed information can be found in the enclosed Premium Wireless by PIEGA user manual.

What can you expect from the product?

Our active wireless high-end speakers are compatible with your existing multiroom system or can be connected directly via Bluetooth.


1 UNPACK YOUR NEW PIEGA CONNECT

Make sure that the following items are included in the scope of delivery:




User manual
- Premium Wireless by PIEGA

USB Micro-B to
USB Type A cable



Power supply unit

Stereo Chinch
cable



PIEGA connect

Coaxial cable

Optical cable

2 SET UP PIEGA CONNECT


Start with the setup of PIEGA Connect. You will find various connection options on the back of the device.

Volume control 1:

Select "fix" to bypass the volume control of PIEGA Connect, i.e., the volume buttons 12 are deactivated. This setting is useful when using a multi-room system, playing music via Bluetooth, etc.

Select "var" to use the volume control of PIEGA Connect 12. This setting is useful when using a CD player, turntable, etc.

Supply PIEGA Connect with power 11:
Please use the enclosed power adapter.



3 SET UP INPUT SOURCE


Connect your existing multi-room system, TV, CD player, turntable etc., to PIEGA Connect. If you only want to use PIEGA Connect via Bluetooth, move on to Step 6.

Select music source 5:

The PIEGA connect has various input source setting options (analog, optical, coaxial). The input sources (e.g. TV, subwoofer, network player, turntable, etc.) can be preset and prioritized as desired. If, for example, you give priority to the TV setup no matter which other input source is running the signal of your TV always overrides.


Important: Bluetooth always has the highest priority! Consequently, bluetooth overrides all other input sources incl. prioritized. This automatic switch function, allows you to play music directly from your device via bluetooth at all times.

Configuration example



4 NOW UNPACK YOUR SPEAKERS


Make sure that the following items are included in the scope of delivery:



Cable




Premium Wireless by PIEGA
user manual




Speaker

5 DECIDE ON SPEAKER POSITION I/II


The following speaker positions 3 are available to you:




Neutral: neutral audio tuning. This position is recommended for speakers that are placed at least 50 cm from the wall.



Wall: This position is recommended for speakers that are placed less than 50 cm from the wall.





Corner: This position is recommended for speakers that are placed in a room corner.



6 DECIDE ON SPEAKER POSITION II/II

For your speakers 4, select whether you would like them to be placed on the left or right.


If you only use one speaker, select mono.



7 POWER SUPPLY


Connect your speakers to the power supply 8.

YOUR WIRELESS SYSTEM IS NOW READY TO USE.



8 CONNECT VIA BLUETOOTH

By pressing the pairing key 13, PIEGA Connect is recognised by your BLUETOOTH device (mobile). The pairing mode is indicated by flashing of the pairing button 13.



WE WISH YOU AN UNFORGETTABLE MUSIC EXPERIENCE!

Do you require more information to successfully install the device? The enclosed user manual provides additional information as well as answers to the most common questions.

The warranty registration and further useful tips and tricks can be found on our website.



PIEGA
SWITZERLAND

DEUTSCH
SEE THE BACKSIDE FOR ENGLISH

QUICK GUIDE

PIEGA CONNECT
Premium Wireless by PIEGA

EXPECT MORE

PIEGA CONNECT
Premium Wireless by PIEGA

QUICK GUIDE

Vielen Dank!

Wir freuen uns, dass Sie sich für unser Premium Wireless by PIEGA entschieden haben! Anhand dieses Quick Guides möchten wir Sie einfach und schnell zu Ihrem Musikerlebnis hinführen.

Wie können Sie es verwenden?

Um Ihr neu erworbenes PIEGA connect zu aktivieren, befolgen Sie einfach die untenstehenden Schritte. Ausführlichere Informationen finden Sie in der beiliegenden Bedienungsanleitung Premium Wireless by PIEGA.

Was dürfen Sie vom Produkt erwarten?

Unsere aktiven Wireless High End Lautsprecher sind mit Ihrem bestehenden Multiroom System kompatibel oder können direkt über Bluetooth verbunden werden.


1 PACKEN SIE IHR NEUES PIEGA CONNECT AUS

Stellen Sie sicher, dass die folgenden Elemente im Lieferumfang enthalten sind:




Bedienungsanleitung
Premium Wireless by PIEGA

USB Micro-B zu
USB Type A Kabel



Netzgerät

Stereo Chinch
Kabel



PIEGA connect

Koaxiales Kabel

Optisches Kabel

2 PIEGA CONNECT EINRICHTEN

Starten Sie mit der Einrichtung vom PIEGA connect. Auf der Rückseite des Gerätes finden Sie die Anschlussoptionen.

Lautstärke Regelung 1:


Wählen Sie "fix" um die Lautstärke Regelung des PIEGA connects zu umgehen, d.h. die Lautstärke Tasten 12 sind deaktiviert. Diese Einstellung eignet sich bei der Verwendung eines Multiroom Systems, Abspielen via Bluetooth usw.

Wählen Sie "var" um die Lautstärke Regelung des PIEGA connect 12 zu verwenden.

Diese Einstellung eignet sich bei der Verwendung eines CD Spielers, Plattenspielers, usw.

Versorgen Sie Ihr PIEGA connect mit Strom 11:

Bitte verwenden Sie dazu den beiliegenden Strom Adapter.



3 EINGANGSQUELLE EINRICHTEN


Verbinden Sie Ihr existierendes Multiroom System, TV, CD Player, Plattenspieler etc. mit Ihrem PIEGA connect. Falls Sie das PIEGA connect nur via Bluetooth verwenden möchten, gehen Sie weiter zu Schritt 6.

Music Source auswählen 5

Das PIEGA connect verfügt über verschiedene Eingangsquellen (Analog, Optical, Coax). Die Eingangsquellen können je nach gewünschter Anwendung (TV, Subwoofer, Networkplayer, Plattenspieler, etc.) voreingestellt bzw. priorisiert werden. Geben Sie beispielsweise dem TV Setup priorität, so wird, egal welche anderen Eingangsquellen laufen, dem Signal Ihres TVs Vorrang gegeben.


Wichtig: Es gilt zu beachten, dass Bluetooth immer die oberste Priorität hat und somit alle anderen Eingangsquellen übersteuert. Sie können folglich Musik jederzeit direkt von Ihrem Gerät über Bluetooth abspielen.

Beispielkonfigurationen




4 PACKEN SIE NUN IHRE LAUTSPRECHER AUS


Stellen Sie sicher, dass die folgenden Elemente im Lieferumfang enthalten sind:



Stromkabel



Bedienungsanleitung





Lautsprecher

6 LAUTSPRECHER POSITIONIERUNG BESTIMMEN II/II

Wählen Sie bei Ihren Lautsprechern 4 aus, ob sie links oder rechts platziert werden.

Sollten Sie nur einen Lautsprecher verwenden, wählen Sie mono.



WIR WÜNSCHEN IHNEN EIN UNVERGESSLICHES KLANGERLEBNIS!

Benötigen Sie zur erfolgreichen Installierung weitere Informationen? In den beiliegenden Bedienungsanleitungen finden Sie zusätzliche Hinweise sowie auch Antworten auf die gängigsten Fragen.

Die Garantieregistrierung sowie weitere nützliche Tipps und Tricks finden Sie auf unserer Website.




PIEGA
SWITZERLAND

7 STROMVERSORGUNG

Schliessen Sie Ihre Lautsprecher an den Strom an 8.

IHR WIRELESS SYSTEM IST NUN EINSATZBEREIT!



8 VERBINDEN SIE ÜBER BLUETOOTH

Durch Betätigen der Pairing-Taste 13 wird das PIEGA connect von Ihrem BLUETOOTH-Gerät (Mobile) erkannt. Der Pairing-Modus wird durch Blinken der Pairing-Taste 13 angezeigt.

